



Suppliers of Tapping Equipment...

ARM-950 Series Tapping Arm Technical...




Model Number	Tapping Range	Working Area		RPM	Collet Type	Weight
		Min	Max			
ARM-950-8	M2 to M8	100	950	700	TYPE1	18kg
ARM-950-12	M3 to M12	100	950	400	TYPE1	18kg

Quick change collet chuck...




The pneumatic motor is equipped with a chuck and each tap is held in its own collet (collets supplied separately). To change to a different tap size, lift the locking ring on the chuck. This will eject the collet from the motor. Select the collet with the desired tap size. Insert the collet into the chuck. Locate the two drive pegs on the collet and release the locking ring to secure.

Quick change tap collets (collets supplied separately)...



Collet Type	D	D1	D2	L1	L3	L4	L5
TYPE 1	23	12.5	13	15	20	19.5	21
TYPE 2	50	30	31	30	31	35	33



Images & Content © Allendale Electronics Limited.
E&OE - Specifications subject to change without prior notice.